

ASSEMBLY AND INSTALLATION INSTRUCTIONS

WARNING:

TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF
POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirement.

1. Insert the terminal into the connector, then fix the fixture arm(B) onto the fixture arm(A) by the mounting screw, and screw it by screwdriver.
2. Assemble the nipple(A) onto the cross bar, and lock it in place by hex nut.
3. Attach the cross bar to outlet box using 2 outlet box screws upwards.
4. Determine the length of the chain you need using pliers to disconnect the extra chain and discard it away.
5. Weave fixture wires and ground wire through the fixture loop, every other chain links, top loop, top nut, canopy and nipple(A); secure the top loop to the nipple(A) and hang the chain to the top loop and fixture loop.
6. Make wire connections:
 - Attach ground wire to house ground wire using a wire nut or attach them to the cross bar with a green ground screw.
 - Attach white wire from light to white wire from power source with a wire nut.
 - Attach black wire from light to black wire from power source with a wire nut.

Observing: positive wire with positive wire, negative wire with negative wire, ground wire with ground wire.
7. Tuck the wire connections neatly into the outlet box.
8. Attach the canopy to the ceiling, and secure it with top nut.
9. Adjust the position of the fixture arm so the column on fixture arm align with the fixture ring, lock with metal nut.
10. Align the holes on the glass panel with the fixture arm glass holder holes secure the glass panel by the sequence of rubber pad, glass panel rubber pad, and metal nut.
11. Install bulb. (not included) (Please do not exceed the maximum capacity which is recommended on the fixture.)
12. Turn on the power at fuse or circuit box.

