







703-6-69
703-8-69
703-9-69
703-11-69



7040-86
7040-1-86
7040-3-86



7027-2-69
7027-3-69
7027-4-69



715-5-69
715-6-69



3-743-15
3-744-15
3-745-15

Relamping instructions

- 1) Remove top cover or fixture cage by unscrewing finial or screws
- 2) Replace bulbs
- 3) Replace top cover or fixture cage and tighten screws

