







7041-1-86  
7041-3-86



7412-10-69




7028-4-69



723-11-37/69

#### Relamping instructions

- 1) Remove bottom finial or remove the screws attaching the cage assembly to fixture
- 2) Replace bulbs
- 3) Replace cage assembly and finial or screws



**ETL**  
Intertek  
american  
lighting  
association  
CHAIN HUNG