







7761-3-69/86




7120-3/69/95




7111-3-3/69/86
7111-4-3/69/86



7699-3/69/86




704-8-69
704-9-69



7216-3-69

Relamping instructions

- 1) Remove bottom finial or remove the screws attaching the cage assembly to fixture
- 2) Replace bulbs
- 3) Replace cage assembly and finial or screws



Intertek
american
lighting
association
CHAIN HUNG