






7041-1-86


7041-3-86




7412-10-69



7028-4-69




723-11-37/69



726-16-69

Relamping instructions

- 1) Remove bottom finial or remove the screws attaching the cage assembly to fixture
- 2) Replace bulbs
- 3) Replace cage assembly and finial or screws



american
lighting
association

CHAIN HUNG