







737-18-69



702-69/86




9718-7-37/69



712-18-69

Relamping instructions

- 1) Remove bottom finial or remove the screws attaching the cage assembly to fixture
- 2) Replace bulbs
- 3) Replace cage assembly and finial or screws



american
lighting
association

CHAIN HUNG