








7511-8-86




7201-9-86




7247-9-3
7247-9-86
7247-9-69




765-8-95




7917-9-86
7917-9-186




7923-9-44




7273-86
7273-69




7941-7-86
7941-7-3
7941-7-69



7902-1-86



7902-3-86



768-11-86

Relamping instructions

- 1) Remove bottom finial or remove the screws attaching the cage assembly to fixture
- 2) Replace bulbs
- 3) Replace cage assembly and finial or screws

