







7760-69/86
7760-3-69/86
7760-4-69/86




7118-3/69/95
7119-3/69/95




730-3/69/86




7696-3/69/86
7697-3/69/86
7698-3/69/86



731-3/69/86




750-3/86
751-3/86



706-69/86

Relamping instructions

- 1) Remove top cover or fixture cage by unscrewing finial or screws
- 2) Replace bulbs
- 3) Replace top cover or fixture cage and tighten screws



WALL MOUNT