





7761-3-69/86




7120-3/69/95



7111-3-3/69/86
7111-4-3/69/86




7699-3/69/86



704-8-69
704-9-69

Relamping instructions

- 1) Remove bottom finial or remove the screws attaching the cage assembly to fixture
- 2) Replace bulbs
- 3) Replace cage assembly and finial or screws



american
lighting
association

CHAIN HUNG