

WARNING! RISK OF ELECTRIC SHOCK

All electrical connections must be in accordance with local codes, ordinances, or national codes. If you are unfamiliar with methods of installing electrical wiring, secure the services of a qualified electrician.

Before starting installation, disconnect the power by turning off the circuit breaker or removing the fuse at fuse block. Turning power off using fan switch (speed control on/off) is not sufficient to prevent electrical shock.

NOTE: The important safeguards and instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors which cannot be built into any product. These factors must be supplied by the person (s) caring for and operating the unit.

1. Reattach the detachable switch housing from the ceiling fan, then remove the plug in bottom of fan's switch housing. (Figure 1)
2. Feed 2 wires from top of light kit fitter through hole in bottom of fan's switch housing. Fitter's threaded conduit should screw into the switch housing, then secure the light kit onto the detachable switch housing with washer and nut provided.(Figure 2)
3. Make polarized wire connection for 2 light kit wires to 2 wires inside the switch housing that are marked "FOR LIGHT", connect white to white wires and black to blue wires.(Figure 2)
4. Make the 9-pin wire connection for the wires from the switch housing and the wires from the ceiling fan.(Figure 3)
5. Install the detachable switch housing to the ceiling fan with 3 screws provided. (Figure 3)
6. Install 1 x 9 Watt LED bulb (included). (Figure 3)
7. Restore power only after installation is completed.

