

## CEILING FAN LIGHT KIT INSTALLATION INSTRUCTION

Model: 2444-8080

## READ AND SAVE THESE INSTRUCTIONS

## **WARNING! RISK OF ELECTRIC SHOCK**

All electrical connections must be in accordance with local codes, ordinances, or national codes. If you are unfamiliar with methods of installing electrical wiring, secure the services of a qualified electrician.

Before starting installation, disconnect the power by turning off the circuit breaker or removing the fuse at fuse block. Turning power off using fan switch (speed control on/off) is not sufficient to prevent electrical shock.

**NOTE:** The important safeguards and instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors which cannot be built into any product. These factors must be supplied by the person (s) caring for and operating the unit.

- 1. Remove the plug from the switch housing. (Fig.1) Attach the light kit to the switch housing by feeding the light kit wires (black and white) through the hole of switch housing and then screw it onto the switch housing by nut & lock washer. Be sure it is tight enough to prevent light kit from vibrating loose. (Fig. 1)
- 2. Locate two single white and blue wires in the switch cup labeled "FOR LIGHT". Make the wire connections as follows and secure with the wire nuts provided:
  - Connect white wire from switch housing to white wire from light kit
  - Connect blue wire from switch housing to black from light kit
- 3. Carefully push all wires back into the switch housing, then install the light kit assembly onto the switch housing plate with 3 screws provided. Be sure to tighten all screws. (Fig. 2)
- 4. Remove the socket ring from the socket by turning the lock ring counter-clockwise until it unlocks. Insert the glass shade into the glass holder and turn the socket ring clockwise to tighten the glass shade. Repeat for the remaining glass shades. (Fig. 2)
- 5. Install 4 x 9 Watt LED bulbs (included). (Fig. 2)
- 6. Restore power and your light kit is ready for operation.

