

ASSEMBLY AND INSTALLATION INSTRUCTIONS

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE : Before installing, consult local electrical codes for wiring and grounding requirement

1. Assemble the nipple(B) onto the cross bar and lock it in place by hex nut(A).
2. Attach the cross bar to outlet box using 2 outlet box screws upwards.
3. Determine the length of the chain you need using pliers to disconnect the extra chain and discard it away.
4. Determine the quantity/length of stem/stems(F) needed.
5. Thread one stem(F) onto the nipple(G) and thread one stem nipple(K) onto the stem(F).
6. Feed fixture wires and ground wire through the nipple(G) or stem nipple(K) and stem(F).
7. Thread the other stem nipple(K) onto the other stem(F) and thread them onto top of the stem(F).
8. Repeat step 6 and step 7 until all desired stems(F) are connected, then thread the fixture loop(E) onto top of the stems(F).
9. Hook quick links onto the both ends of the chain and hang the chain to the top loop and the fixture loop(E).
10. Weave fixture wires and ground wire through the fixture loop(E), every other quick and chain links, top loop, canopy(C) and nipple(B).
11. Make wire connections:
 - Attach ground wire to house ground wire using a wire nut or attach them to the cross bar with a green ground screw.
 - Attach white wire from light to white wire from power source with a wire nut.
 - Attach black wire from light to black wire from power source with a wire nut

Observing: positive wire with positive wire, negative wire with negative wire, ground wire with ground wire.

12. Tuck the wire connections neatly into the outlet box.
13. Attach the canopy to the ceiling, and let the nipple(B) protrude through the pre-drilled hole on the canopy(C) and secure with finial(D).
14. Install bulb.(not included) (Please do not exceed the maximum capacity which is recommended on the fixture.)
15. Assemble the glass sheet(I) onto the frame(H) by finials(J).
16. Turn on the power at fuse or circuit box.

